

INSTALLATION OPERATION & MAINTENANCE GUIDE




HIGH PRESSURE CONTROL VALVES

STEM-GUIDED, NON-BALANCED

Valve Connection Size	Seat and Cage Removal Tool	Seat Removal Tool	Diaphragm Nut Wrench	
1"	3032	615	476DNW	Contrad Cons Dou
2"	3033	614	4356DNW	Seat and Cage Rei 3032 3033

CAGE-GUIDED, BALANCED

Valve Connection Size	Seat Installation Tool	Upper Cage Puller	Diaphragm Nut Wrench
2"	6670	5296	4356DNW
3"	3 " 6826		4965DNW
4"	5561	5298	4965DNW
6"	5561	6402	
8"	5561	6651	
10"	5561	6651	




THREE-WAY VALVES

		1" Valve Connection	2" Valve Connection	3" Valve Connection
Diaphragm Balanced 3-way S	Diaphragm Nut Removal Tool	N/A	1471SNW	N/A
	Spring Compression Tool	N/A	5534	N/A

	Diaphragm Nut Removal Tool	N/A	1471SNW	1859SNW
Piston Balanced 3-way	Spring Compression Tool	N/A	5534	5535
	Upper Seat Wrench	N/A	2276SW	N/A

High Pressure 3-way	Lower Seat Wrench	2130SW	N/A	N/A







Upper Seat Wrench 2276SW

б

Lower Seat Wrench 2130SW

Splitter Valve

No Special Tools Needed

LOW PRESSURE CONTROL VALVES

LOW PRESSURE, NON-BALANCED


		1/2" Trim	1" Trim
1" Valve	Seat Removal Tool	1349SW	Not Needed
Connection	Stem Guide	6431	1851

		1" Trim, Ductile Body	1" Trim, Steel Body	2" Trim
2" Valve	Seat Removal Tool	706HTSW	4005SW	272SW
Connection	Stem Guide	1852		1852


		1-5/8" Trim, Ductile Body	1-5/8" Trim, Steel Body	3" Trim
3" Valve	Seat Removal Tool	1219HTSW	1219SW	273SW
Connection	Stem Guide	1853		1853

		2" Trim, Ductile Body	2" Trim, Steel Body	4" Trim
4" Valve	Seat Removal Tool	1220HTSW	1220SW	274SW
Connection	Stem Guide	1854		1854


		3" Trim, Ductile Body	3" Trim, Steel Body	6" Trim
6" Valve	Seat Removal Tool	1221HTSW	1221SW	275SW
Connection	Stem Guide	1855		1855



Seat Removal Tool 706HTSW 1219HTSW 1220HTSW 1221HTSW 1349SW



Seat Removal Tool 4005SW 1219SW 1220SW 1221SW






Seat Removal Tool 272SW 273SW 274SW 275SW

LEVER OPERATED LIQUID DUMP VALVES




	Diaphragm Balanced	Piston Balanced	Piston Balanced Throttling
Valve Connection Size	No Special Tool Requried	No Special Tool Requried	Seat Removal Tool
2″	N/A	N/A	272SW
2″ with 1″ Reduced Trim	N/A	N/A	7701SW for CXA5 272SW for CAZ5
3″	N/A	N/A	273SW
4″	N/A	N/A	
6″	N/A		-





Seat Removal Tool 273SW




Seat Removal Tool 7701SW



	2" Valve Connection	3" Valve Connection	4" Valve Connection	6" Valve Connection
Seat Wrench	384SW	385SW	386SW	1771SW



Seat Wrench 384SW 385SW 386SW




PNEUMATICALLY OPERATED LIQUID DUMP VALVES



		2" Valve Connection	3" Valve Connection	4" Valve Connection	6" Valve Connection
Diaphragm Balanced	Diaphragm Nut Removal Tool	1471SNW	1472SNW	Not Needed	706HTSW
	Spring Compression Tool	5534	5535	5535	6447
	Stem Guide Wrench	2463SW	2464SW	2464SW	N/A
	Stem Guide (O-Ring Protector)	1852	1853	1854	1855

	Piston Removal Tool	1471SNW	1859SNW	1859SNW	
Piston	Spring Compression Tool	5534	5535	5535	
Balanced	Stem Guide Wrench	2463SW	2464SW	2464SW	
	Stem Guide (O-Ring Protector)	1852	1853	1854	

	Seat Removal Tool	272SW	273SW	274SW	
Piston	Spring Compression Tool	5534	5535	5535	
Balanced Throttling	Stem Guide Wrench	N/A	N/A	N/A	
	Stem Guide (O-Ring Protector)	1852	1853	1854	





PNEUMATIC

		1/2" Trim	1" Trim
1" Valve	Seat Removal Tool	1349SW	
Connection	Stem Guide	1851	
		1" Trim	2" Trim
2" Valve	Seat Removal Tool	1" Trim 4934SW	2" Trim 272SW

		1-5/8" Trim	3" Trim
3" Valve Connection	Seat Removal Tool	Ductile - 1219SW Steel - 1219HTSW	273SW
Connection	Stem Guide	1853	


		2" Trim	4" Trim
4" Valve Connection	Seat Removal Tool	Ductile - 1220SW Steel - 1220HTSW	274SW
Connection	Stem Guide	1854	


		3" Trim	6" Trim
6" Valve Connection	Seat Removal Tool	Ductile - 1221SW Steel - 1221HTSW	275SW
Connection	Stem Guide	1855	

SPRING-LOADED BACK PRESSURE

		1" Trim, Ductile Body	1" Trim, Steel Body	2" Trim
2" Valve	Seat Removal Tool	4005SW	4060SW	272SW
Connection	Stem Guide	1852		

		1-5/8" Trim, Ductile Body	1-5/8" Trim, Steel Body	3" Trim
3" Valve	Seat Removal Tool	1219HTSW	N/A	273SW
Connection	Stem Guide	1853		







Seat Removal Tool 272SW 273SW 274SW 275SW




Seat Removal Tool 4934SW



Seat Removal Tool 1219SW 1220SW 1221SW



Seat Removal Tool 1219HTSW 1220HTSW 1221HTSW 1349SW



Seat Removal Tool 4005SW 4060SW



Stem Guide 1852 1853

GLYCOL PUMPS

	Suction Seat Removal Tool	Seal Retainer Tool	Suction Seat Insertion Tool
1720 PV	615	4456	1542
2020 SC	615	4456	1542
4020 PV	615	4456	1542
5020 SC	614	4457	1543
9020 PV	614	4457	1543
10020 SC	614	4458	1544
21020 PV	614	4458	1544
20020 SC	614	4459	1545
45020 PV	614	4459	1545

) o

വി

Suction Seat Removal Tool Seal Retainer Tool

Suction Seat Insertion Tool

WHO WE ARE

Kimray is a manufacturer of oil and gas control equipment based in Oklahoma City, Oklahoma, USA.

Trusted for generations, Kimray has been creating simple, effective solutions for temperature, level, flow, and pressure control since 1948. Common applications include separation, heating, compression, dehydration, and artificial lift.

Buying from Kimray is about much more than the product. We are partners with hearts to serve. The relationships between our representatives and our customers extend from before the sale through the life of the product. Our focus is not on shortterm profits but long-term growth for our customers.

Visit Kimray.com to learn more about our company and the products we create.



Kimray.com

