


## REPAIR KIT MANUAL VALVE POSITIONER

ITEM	QTY.	DESCRIPTION	PART NUMBER
1	1	O Ring	157
2	1	O Ring	520
3	4	Packing Ring	533
4	1	Packing Sleeve	534
5	2	Felt Wiper	527
6	2	Snap Ring	940
7	1	O Ring	156
8	1	Thrust Washer	1846
9	1	O Ring	530
10	1	O Ring	537





REPAIR KIT MANUAL VALVE POSITIONER

